

712 - MICROWAVE OVEN CLEANER

MICROWAVE OVEN CLEANER is an easy biodegradable, cleaner for microwave ovens, both in- and out-side. The cleaner efficiently dissolves grease and burnt-in food residues inside the oven, removes bad odor, and leaves the microwave oven sparkling clean.

Instructions

Spray on the insides of the microwave oven. Allow 15 minutes for the cleaner to work and wipe off with a cloth. Surfaces with heavy contamination may require repeated treatment.

Declaration

Contains: <5% amphoteric and non-ionic surfactants. Also contains: water, isopropanol and perfume.

WARNING: Keep out of reach of children.



Conditioning

500ml (12 units/box)

If you have any questions, please contact our Technical Department on: +45 4817 6970